

Replacing Gaskets on Beta™ Water Sampling Bottles

Introduction:

The replacement gaskets for the Beta™ bottles are made from a foam silicon material. This material does not glue well to other materials, so it comes with an adhesive material already applied to one side of it. This adhesive, however, is not sufficiently strong enough to adhere to the white end seal.

In order for the foam gasket to properly adhere to the white end seals, an additional adhesive must be used. The recommended adhesive would be any form of **super glue** (cyanoacrylate). Super glue is not included.

Warranty and Parts:

We replace all missing or defective parts free of charge. For additional parts, use part numbers above. We accept Mastercard, Visa, American Express, checks, institutional P.O.'s. All products guaranteed free from defect for 90 days. This guarantee does not include accident, misuse, or normal wear and tear.

How To Install:

1. Remove any existing foam gasket material from the white Beta™ bottle end seals.
2. Roughen the surface of the white end seal where the foam gasket will be installed with coarse grit sandpaper. This will help the gasket adhere to the end seal better.
3. Apply a small amount of super glue to the entire area where the gasket will be applied.
4. Remove the backing from the foam gasket.
5. Install the foam gasket, adhesive side down, making sure that the ends of the gasket touch each other when completely installed.

P/N 031871

© Wildlife Supply Co. Wildco® and Wildlife Supply Co are registered trademarks of Morris & Lee Inc. All rights reserved.

